

ASSEMBLY INSTRUCTION

STF-2816/2817/2019/2820

A-10 (4x75mm)



B-01




C-10



D-01



E-01



STEP - 01

Wall


Wall plug

Wall Mount

Screw



Screw drive

STEP - 02



STEP - 03

STEP - 04



Final

